



Important: coolant flow must be started prior to rotating the spindle to avoid damage of the O-rings

Please verify that the weight of the entire tool assembly does not exceed the machine spindle's carrying capability